





Border punch

How to use

Start with your punch on a craft mat to make sure you don't scratch your table. Center your paper (for perfectly centered borders) and slide it into the punch flush to the back and punch.



Don't pull the paper out! Slide it to the left keeping it flush to the back until the newly punched pattern lines up with the printed pattern on the base and punch again. Repeat on both sides of your center punch until you complete your border.



www.fiskars.com

This punch can be used on heavy card stock, but we recommend 65 lb. card stock to get the best results.